



Technical Datasheet

48" VW Wind Machine

Powered by a car engine and due to its adjustable power and directional controls, the 48" VW Wind Machine is ideal for almost any exterior wind effect.

Specifications:

Equipment Size (cm):
H 250 x W 158 x L 283

Equipment Weight (kg):
500+ (Contact MTFX)

Shipping Type:
Trailer

Fuel Type:
Leaded Petrol (contact
MTFX Before Fuelling)

Noise: 95db at 5mtrs

Approx Wind Speeds:
1mtrs: 70mph
3mtrs: 40mph
5mtrs: 20mph

Suggested for set up
2 People

Additional Info:
-Car battery and leaded
fuel required

-Outdoor use only

-The wind machine is
designed to be used on
its trailer.

How to set up and use the 48" Wind Machine

1. Position the trailer on level ground, fasten the handbrake & fix the screw jacks in place (fig. 1)
2. Ensure the fuel tank is filled with leaded petrol. (contact MTFX before fuelling).
3. Partially turn the ignition key (Fig 2) for 3 seconds to pump the fuel and then fully turn to fire the engine.
4. Use the throttle (Fig 3) on the right handle to control the output.
5. Monitor the output using the rev counter gauge (Fig 4).
6. The wind machine can be directed left or right by turning the handles. To unlock, swing the release bar to the open position (Fig 6).
7. To tilt up or down swing the release bar to the open position, this will allow you to direct the machine up or down (Fig 5).
8. After use turn ignition key back to off position.

Hints/Tips/Safety

1. Ensure the Screw Jacks and handbrake are secured before use.
2. Keep hands, hair and all objects away from the fan blades. Be aware of loose objects such as ties.
3. The machine is very loud so ear defenders will be required.
4. Do not touch any engine components as this may result in burns.
5. Fire fighting equipment must be readily available.
6. If smoke or debris is to be used in the effect always keep it in front of the blades. Taking it behind the fan whilst in use will damage the machine and risks injury to the operator.



Fig 1. Handbrake & Screw Jacks




Fig 2. Ignition Key



Fig 3. Throttle



Fig 4. Rev Counter



Fig 5. Tilt Control



Fig 6. Swivel lock

vimeo.com/230775406



Velt House, Velt House Lane, Elmore, Gloucester, GL2 3NY
T: 01452 729903 E: info@mtfx.com www.mtfx.com



Technical Datasheet

48" VW Wind Machine

Specifications:

Equipment Size (cm):
H 250 x W 158 x L 283

Equipment Weight (kg):
500+ (Contact MTFX)

Shipping Type:
Trailer

Fuel Type:
Leaded Petrol (contact
MTFX Before Fuelling)

Noise: 95db at 5mtrs

Approx Wind Speeds:
1mtrs: 70mph
3mtrs: 40mph
5mtrs: 20mph

Suggested for set up
2 People

Additional Info:
-Car battery and leaded
fuel required

-Outdoor use only

-The wind machine is
designed to be used on
its trailer.



vimeo.com/230775406



Velt House, Velt House Lane, Elmore, Gloucester, GL2 3NY
T: 01452 729903 E: info@mtfx.com www.mtfx.com