



# Technical Datasheet

## Handheld Blower

### Specifications:

Equipment Size (cm):  
H23 x W18 x L50

Equipment Weight (kg):  
2

Shipping Type:  
Flightcase or similar

Shipping Size (cm):  
Contact MTFX

Shipping Weight (kg):  
Contact MTFX

Power Requirements:  
Connector:16A  
Voltage: 240v  
Peak Amps: TBC  
Running Amps: TBC

Noise: 75db at 3mtrs

Wind Speeds:  
1mtrs: 19mph  
5mtrs: 1.8mph  
10mtrs: 0mph

Suggested for set up  
1 Person

The Handheld Blower is a simple yet effective wind machine. Ideal for creating smaller wind effects, with built in speed controls the machine uses a 16A connector on a 240V supply.

### How to set up and use the Handheld Blower:

1. Plug in the power supply
2. Wind speed is increased by increasing pressure on the trigger. To start the unit, simply pull the trigger. Release the trigger to stop.
3. For continuous operation, pull the trigger and then push in the lock button. To release the unit from the locked position pull the trigger fully, then release it.
4. A speed control screw is provided so that unit speed can be changed at the fully-pulled trigger position. Turn the speed control screw clockwise (+) for higher speed, and counter clockwise (-) for lower speed.



Fig.2 Variable speed controller

### Hints/Tips/Safety:

1. Before plugging in the wind machine, always check to see that the trigger switch actuates properly and returns to the "OFF" position when released.



Fig.1 Handheld Blower

[vimeo.com/207098788](https://vimeo.com/207098788)



**Velt House, Velt House Lane, Elmore, Gloucester, GL2 3NY**  
**T: 01452 729903 E: info@mtfx.com www.mtfx.com**