



Technical Datasheet

Inline Blower

The Inline Blower is a compact but effective blower or wind machine, which can also be used to extract air.

How to set up and use the Inline Blower

1. Plug in the power supply
2. Switch the unit on
3. To switch between blow/suck simply turn the unit around to achieve desired effect
4. On request an optional 4mtr hose can be supplied

Safety

1. Keep hands, hair and all objects away from the fan blades. Be aware of loose objects such as ties.

Specifications:

Height : 42cm

Width : 35cm

Depth : 35cm

Shipping weight : 16kg

Voltage : 240v

Power connector : 16A

Amps drawn : 3.6A

Packaging type : Box

Noise : 75db at 3mtrs

Suggested for set up :
1 person

Duration of effect :
Continuous

Air power :
1mtr : 15.0mph
5mtrs : 7.5mph
10mtrs : 2.8mph



Fig 1. Clarke Air Blower



Fig 2. On/off switch



Fig 3. Optional hose